

45mm Roller Material Cutter


OL45C

WHEN BLADE GETS DULL

When the blade is no longer sharp, loosen the wing nut on the back of the main body, rotate the blade by one scale for a new cutting edge.

One RB45 blade has 12 cutting edges.

*Blade is extremely sharp. Handle with care.



HOW TO REPLACE BLADE

Loosen the wing nut, remove the screw, and set a new blade as shown in the figure.

*Blade is extremely sharp. Handle with care.

