


CHANGING BLADE INSTRUCTIONS

For Safety Knives including
Models: SK-4, SK-7, SK-9



1 Push slider forward until black "wings" are centered in channel opening.



2 Lift slider assembly.




3 Carefully remove used blade. Flip end-to-end for new edge or rotate 180° for left-handed use. Dispose of fully used blade properly in sharps container.



4 Insert blade into channel.

CHANGING BLADE INSTRUCTIONS

For Safety Knives including
Models: SK-4, SK-7, SK-9



- 5** Center hole in blade between channel tabs. Slightly pull slider forward and down to align circle on slider with the hole in the blade.



- 6** New blade is now ready for use.